

Compatibility Note II :

1. The table displays the default factory settings. You can reassign specific key functions using the Norwii Presenter software.

2. Bluetooth connectivity requires BLE driver support in the operating system and Bluetooth hardware version BLE 4.0 or higher. Devices running Windows 7 typically cannot establish a Bluetooth connection.

Operation System→		Windows 7 and above				macOS			Android 4.4 and above		iOS(Test by iPad)			Linux(Ubuntu 18.04)	ChromeOS
Function of the presenter	Corresponding keyboard function	MS Office ^[4]	WPS	Open office	Prezi	Keynote	MS Office 365	Prezi	WPS	MS office	Keynote	WPS	MS Office	LibreOffice 6	Google Slides
Page Up	Page Up	√	√	√	√	√	√	√	√	√	X	X	X	√	√
Page Down	Page Down	√	√	√	√	√	√	√	√	√	X	X	X	√	√
Arrow Up	Arrow Up	√	√	√	√ ^[2]	√	√	√ ^[2]	√	√	√	√	√	√	√
Arrow Down	Arrow Down	√	√	√	√ ^[2]	√	√	√ ^[2]	√	√	√	√	√	√	√
Arrow Left	Arrow Left	√	√	√	√	√	√	√	√	√	√	√	√	√	√
Arrow Right	Arrow Right	√	√	√	√	√	√	√	√	√	√	√	√	√	√
Scroll Up	Scroll Up	√	√	√	√ ^[2]	X	√	√ ^[2]	√	X	X	√	X	√	√
Scroll Down	Scroll Down	√	√	√	√ ^[2]	X	√	√ ^[2]	√	X	X	√	X	√	√
Full Screen	Shift+F5..... ^[1]	√	√	√	X ^[3]	√	√	X ^[3]	X	X	√	X	X	√	X ^[5]
Escape Full Screen	ESC	√	√	√	√	√	√	√	√	√	√	√	√	√	√
Black Screen	b	√	√	√	√	√	√	√	X	√	√	√	√	√	√
Annotation	Ctrl/Command + P	√ ^[7]	√	X	X	X	√ ^[7]	X	X	√	X	X	X	X	X
Eraser	e	√ ^[7]	√	X	X	X	√ ^[7]	X	X	√	X	X	X	X	X
Mouse Enable	Mouse Move	√	√	√	√	√	√	√	√	√	X	X	X	√	√
Mouse Left	Mouse LeftClick	√	√	√	√	√	√	√	X	X	X	X	X	√	√
Mouse Right	Mouse RightClick	√	√	√	√	√	√	√	√	√	X	X	X	√	√
Volume Control	Vol up/down	√	√	√	√	√	√	√	√	√	√	√	√	√	√
Virtual Laser ^[6]	Ctrl/Command+L	√ ^[7]	X	X	X	X	√ ^[7]	X	X	X	X	X	X	X	X

Annotation:

[1] The full-screen function defaults to sending a combination that includes Shift + F5 and Command + Return to ensure compatibility across different presentation software.

[2] In Prezi, Arrow Up/Arrow Down and Scroll Up/Scroll Down control zooming. Therefore, please set your navigation keys to Page Up/Page Down or Arrow Left/Arrow Right for slide control.

[3] Prezi does not have a keyboard shortcut for the full-screen function.

[4] This feature has been tested as compatible with Microsoft Office 2003 as the minimum supported version.

[5] On ChromeOS, the full-screen function can be reassigned via Norwii Presenter software. The default shortcut is Ctrl + Enter.

[6] Virtual Laser refers to the activation of the built-in "Laser Pointer" function in Microsoft PowerPoint 2010 and later versions during full-screen slide show mode. Windows shortcut: Ctrl + L. macOS shortcut: Command + L.

[7] The factory default annotation function and Virtual Laser are configured for Microsoft PowerPoint on Windows. If you use Microsoft PowerPoint on macOS, you must select the macOS compatibility mode in the Norwii Presenter software and update both the software and firmware.