

Wireless Presenter User Manual

N26

Be sure to read this user manual carefully before using the wireless presenter and keep it for future reference.

WARNING

This product can generate laser beam. DO NOT STARE INTO BEAM OR EXPOSE USERS OF TELESCOPIC OPTICS. Do not shine the laser beam on people's or animal's eyes to avoid eye damage! Do not give this product to children as a toy!

Warning label for red laser product:



Safety Precautions

1. Use this product correctly according to this manual.
2. This product is for professional use only. Children under 14 years of age are strictly prohibited from using it.
3. Do not point the laser beam at human eyes, including via mirror reflections.

The Professional Presenter

4. Do not observe the laser beam with naked eyes or using optical instruments (e.g., telescopes or magnifying glasses).
5. Avoid pointing the laser beam arbitrarily at various optical reflective surfaces.
6. Do not intentionally or casually irradiate people.
7. Do not place the product in high-temperature environments or throw it into fire.
8. Do not immerse this product in water or any other liquid.
9. Do not disassemble, impact, or crush the product without authorization. If the product malfunctions, contact Norwii after-sales support.

I. Operation system

Supports Windows 10/11 and macOS 10.15 and later. On Android and Linux systems, only the laser and page up/down functions are supported.

II. Package contents

1. Wireless presenter x 1 (USB receiver stored inside the wireless presenter)
2. User Manual x 1

III. Specifications

Transmitter

Technology: Radio frequency

Frequency: 2.4GHz

Control Distance: 100m

Laser Power: see warning label on the product

Laser Distance: >200m

Wavelength: Red 640-660nm

Battery: AAA x 1

Working Voltage: 1.5V

Dimension: 138.8 x 17.6 x 15mm

Weight: 18.6g

USB receiver


The Professional Presenter

Working Voltage: 4.5-5.5V

Dimension: 24.7 x 13.8 x 5.1mm

Weight: 1.6g

IV. Bluetooth connectivity



1. Bluetooth connection on Windows computer.

1) On the computer, turn on the Bluetooth switch, click Add Device,

and select Bluetooth as the device type.

2) Turn off the power of the wireless presenter, press and hold the wireless presenter's page up key, turn on the wireless presenter's power switch, then release the wireless presenter's page up key. At this time, the wireless presenter's LED will flash, indicating that it is waiting for pairing in the following 3 minutes.

3) On the computer, find the "Norwii N26 BLE" in the "Add device", click connect, and at the same time, the presenter indicator light is off, and display "Norwii N26 BLE" connected in "Bluetooth & device". The presenter can now control the computer.

2. Bluetooth connection on macOS computer.

1) On the computer, select Bluetooth in the computer System Settings and turn on the Bluetooth

switch.

2) Turn off the power of the wireless presenter, press and hold the wireless presenter's page up key, turn on the wireless presenter's power switch, then release the wireless presenter's page up key. At this time, the wireless presenter's LED will flash, indicating that it was waiting for pairing in the following 3 minutes.

3) On the computer, find the "Norwii N26 BLE" on "Nearby Devices", click connect, and at the same time, the presenter indicator light is off, and display "Norwii N26 BLE" connected in "My Computer". The presenter can now control the computer.

3. Priority of USB receiver and Bluetooth connection.

The USB receiver has a higher priority than the computer's Bluetooth. After connecting the

wireless presenter to the computer via Bluetooth, plug in the USB receiver, and the wireless presenter will disconnect from the computer via Bluetooth and establish a connection with the USB receiver. Pull out the USB receiver, and the wireless presenter will automatically connect to the computer via Bluetooth. The wireless presenter cannot be paired with computer via Bluetooth when the USB receiver is plugged in.

4. Bluetooth wireless presenter and device reconnection.

The wireless presenter can store IDs for the 7 most recently connected devices (computers, iPads, phones, etc.). The USB receiver is not included in these 7 devices. After turning on the wireless presenter, the first device that sends a reconnection request with a signal strength greater than -10 dBm will connect to the wireless presenter.


For users: If a computer is among the 7 most recently connected devices, turning the wireless presenter off and then back on within 5 meters (16 feet) of the computer will automatically reconnect the wireless presenter to the computer.

5. To clear the saved device IDs from the wireless presenter:

- 1) Turn off the power switch of the wireless presenter.
- 2) Press and hold the laser key (for the N20 BLE, press the Tab key; for some products without a laser key, press the Pointer key).
- 3) Turn on the power switch.
- 4) Release the key once the LED blinks.



The blinking LED indicates that the wireless presenter has cleared all saved device IDs and has entered Bluetooth pairing mode. Users can perform Bluetooth pairing within the next 3 minutes.

V. Function map




Attention: When using this product, please change your Input Method Editors (IME) to English input mode.



VI. Function Description

1. Power switch: push up to "ON" to turn on the presenter, push down to "OFF" to turn off the presenter.
2. Page up key : click to page up, long press to play slides from the current page. Long press again to end slide show.
3. Page down key : click to page down, long press to enter black

screen, long press again to exit black screen.

4. Physical laser key  : Press and hold to turn on the physical laser beam, and release to turn off the physical laser beam.

5. Function switching the page up and down keys.

Long press  and  simultaneously to switch between the four modes.

1) By default, the page up and down keys on the Bluetooth wireless presenter correspond to the left and right arrow keys on the computer keyboard, which is suitable for PowerPoint, WPS, Prezi, and Keynote.



2) The first time you press and hold both the page up and down keys on the wireless presenter simultaneously, the function will switch to the Page Up and Page Down keys on the computer keyboard. This is suitable for

image-viewing software.

PgUp

PgDn

3) The second time you press and hold both the page up and down keys simultaneously, the function will switch to the mouse scroll wheel function. This is suitable for some short-video apps and web browsers.



4) The third time you press and hold both the page up and down keys simultaneously, the function will switch to the up and down arrow keys on the computer keyboard. This is suitable for Word, Excel, and other applications.



5) The fourth time you press and hold both the page up and down keys simultaneously, the function will switch to the default left and

right arrow keys on the computer keyboard.




6) After switching the function, it will be automatically saved. When you restart the wireless presenter, you can continue to use the switched function.

6. The page up/down keys can be customized by Norwii Presenter software.

VII. Installation

1. Install the battery


The product is powered by a No. 7 AAA battery. After opening the battery cover, place a No. 7 AAA battery and then close the battery cover (as shown in the picture) :




The Professional Presenter

2. Take out the USB receiver and install it.

Plug the receiver into the USB port. The operation systems including Windows, Android and Linux will install the driver for the USB receiver automatically.




(Take out the USB receiver)



(The USB receiver into the computer USB port)

3. Control the wireless presenter by operating the key of the flip pen.
4. Turn off the wireless presenter.



VIII. Frequently Asked Questions

1. How to download Norwii Presenter software and how to pair the presenter and the USB receiver?

For products that support key function customization or highlight serial products that support digital laser, highlight, magnifier, you need to download Norwii Presenter software. Please download it from the "Downloads" under the "Support" menu of Norwii official website www.norwii.com in English version.

2. How to know if the battery is out of power?

When the power is turned on, if the laser button is pressed and no laser

is emitted, it means there is no power at all or the laser module is damaged and needs to be replaced. If other buttons are pressed and the LED indicator light does not indicate, it also indicates that the battery is out of charge. Please replace the AAA battery in a timely manner.

When the battery level is low, the indicator light on the flip pen will enter a slow flashing state, reminding users to replace the AAA battery in a timely manner.

3. Why does the laser pointer not work?

The laser does not light up, please check:

- 1) Is the power switch turned on? If not, turn on the power.
- 2) If the LED of the wireless presenter flashes slowly, it indicates that the battery is low and needs to be replaced with AAA battery
- 3) If other functions of the wireless presenter are normal and only the laser is not on, it indicates that the

laser module is broken and needs replacement.

4. What to do if the laser becomes dim?

The dimming of the laser beam is usually due to low battery power, and it is necessary to replace the AAA battery as soon as possible. If the laser beam is still just a red dark spot after replacing with a new AAA battery, it indicates that the laser module is aging. When the laser module ages, please contact us for after-sales repair.

5. Why does the computer do not detect the device when the USB receiver plugs into the PC?

Please check whether the USB works or not. You can use a USB mouse or keyboard to test the USB port. If a USB mouse or keyboard works on the USB port and the USB receiver of the presenter doesn't work, it means the USB receiver is broken or the USB drivers is not compatible with the USB receiver.

You can try another USB port of the same computer or USB ports of another computer to check whether the USB receiver is good or not. If it works on other computer, it means the USB drivers of the computer are not compatible with the USB receiver. You need to back up your data and reinstall the OS.

6. The laser is ok, and the USB receiver can be detected by the computer, why does the presenter control the computer?

The reason is the USB receiver doesn't save the presenter's address properly. You can use Norwii Presenter software to let the USB receiver to save the presenter's address again. We also call this operation is to PAIR the wireless presenter and the USB receiver.

7. How do you adjust the settings for Norwii Presenter on macOS?

On Apple's macOS, the Norwii

Presenter software requires three permissions: Accessibility, input monitoring, Screen & System Audio Recording. If it has not been set before, please click "Grant Permissions" in the "About" tab of the Norwii Presenter software, and then open the corresponding permission settings in the window that opens. You can also check the box in front of the Norwii Presenter software in the above three permission settings in the "Launchpad - System settings – Privacy & Security – Accessibility, input monitoring, Screen & System Audio Recording" of macOS.

8. In practice, some users have experienced the issue where PowerPoint and Keynote fail to turn pages in full-screen mode after enabling Full Keyboard Access.

On Apple's iOS and iPadOS, when PowerPoint and Keynote are in full-screen mode, pressing the page up

and page down keys on a wireless presenter does not turn the pages. Instead, the cursor focus moves between text areas. Please disable ****Settings -> Accessibility -> Full Keyboard Access****.

IX. FCC Statement

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

X. FCC Radiation Exposure Statement

1. This equipment complies with

The Professional Presenter

FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

2. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined

The Professional Presenter

by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

XI. Certifications

CE, ROHS, FDA

FCCID: 2AXGRN95

XII. Declaration of conformity

This laser product complies with EN 50689:2021 and IEC/EN60825-1:2014/A11:2021. Complies with 21 CFR 1040.10 and 1040.11, except for deviations pursuant to Laser Notice No.50, dated June 24, 2007.

Shanghai Norwii Technology Co.,
Ltd

Address: No.277 Jinfeng Road,
Pudong New Area, Shanghai,
201201, China

Tel: 86-21-51872080

Email: support@norwii.com